

SYNTHETIC PRECIPITATION LEACHING PROCEDURE

1.0 SCOPE AND APPLICATION

1.1 Method 1312 is designed to determine the mobility of both organic and inorganic analytes present in liquids, soils, and wastes.

2.0 SUMMARY OF METHOD

2.1 For liquid samples (i.e., those containing less than 0.5 % dry solid material), the sample, after filtration through a 0.6 to 0.8 μm glass fiber filter, is defined as the 1312 extract.

2.2 For samples containing greater than 0.5 % solids, the liquid phase, if any, is separated from the solid phase and stored for later analysis; the particle size of the solid phase is reduced, if necessary. The solid phase is extracted with an amount of extraction fluid equal to 20 times the weight of the solid phase. The extraction fluid employed is a function of the region of the country where the sample site is located if the sample is a soil. If the sample is a waste or wastewater, the extraction fluid employed is a pH 4.2 solution. A special extractor vessel is used when testing for volatile analytes (see Table 1 for a list of volatile compounds). Following extraction, the liquid extract is separated from the solid phase by filtration through a 0.6 to 0.8 μm glass fiber filter.

2.3 If compatible (i.e., multiple phases will not form on combination), the initial liquid phase of the waste is added to the liquid extract, and these are analyzed together. If incompatible, the liquids are analyzed separately and the results are mathematically combined to yield a volume-weighted average concentration.

3.0 INTERFERENCES

3.1 Potential interferences that may be encountered during analysis are discussed in the individual analytical methods.

4.0 APPARATUS AND MATERIALS

4.1 Agitation apparatus: The agitation apparatus must be capable of rotating the extraction vessel in an end-over-end fashion (see Figure 1) at 30 ± 2 rpm. Suitable devices known to EPA are identified in Table 2.

4.2 Extraction Vessels

4.2.1 Zero Headspace Extraction Vessel (ZHE). This device is for use only when the sample is being tested for the mobility of volatile analytes (i.e., those listed in Table 1). The ZHE (depicted in Figure 2) allows for liquid/solid separation within the device and effectively precludes headspace. This type of vessel allows for initial liquid/solid

in Step 4.2.1 is used for filtration. The device shall be capable of supporting and keeping in place the glass fiber filter and be able to withstand the pressure needed to accomplish separation (50 psig).

NOTE: When it is suspected that the glass fiber filter has been ruptured, an in-line glass fiber filter may be used to filter the material within the ZHE.

4.3.2 Filter Holder: When the sample is evaluated for other than volatile analytes, a filter holder capable of supporting a glass fiber filter and able to withstand the pressure needed to accomplish separation may be used. Suitable filter holders range from simple vacuum units to relatively complex systems capable of exerting pressures of up to 50 psig or more. The type of filter holder used depends on the properties of the material to be filtered (see Step 4.3.3). These devices shall have a minimum internal volume of 300 mL and be equipped to accommodate a minimum filter size of 47 mm (filter holders having an internal capacity of 1.5 L or greater, and equipped to accommodate a 142 mm diameter filter, are recommended). Vacuum filtration can only be used for wastes with low solids content (<10 %) and for highly granular, liquid-containing wastes. All other types of wastes should be filtered using positive pressure filtration. Suitable filter holders known to EPA are listed in Table 4.

4.3.3 Materials of Construction: Extraction vessels and filtration devices shall be made of inert materials which will not leach or absorb sample components of interest. Glass, polytetrafluoroethylene (PTFE), or type 316 stainless steel equipment may be used when evaluating the mobility of both organic and inorganic components. Devices made of high-density polyethylene (HDPE), polypropylene (PP), or polyvinyl chloride (PVC) may be used only when evaluating the mobility of metals. Borosilicate glass bottles are recommended for use over other types of glass bottles, especially when inorganics are analytes of concern.

4.4 Filters: Filters shall be made of borosilicate glass fiber, shall contain no binder materials, and shall have an effective pore size of 0.6 to 0.8- μ m. Filters known to EPA which meet these specifications are identified in Table 5. Pre-filters must not be used. When evaluating the mobility of metals, filters shall be acid-washed prior to use by rinsing with 1N nitric acid followed by three consecutive rinses with reagent water (a minimum of 1-L per rinse is recommended). Glass fiber filters are fragile and should be handled with care.

4.5 pH Meters: The meter should be accurate to ± 0.05 units at 25°C.

4.6 ZHE Extract Collection Devices: TEDLAR[®] bags or glass, stainless steel or PTFE gas-tight syringes are used to collect the initial liquid phase and the final extract when using the ZHE device. These devices listed are recommended for use under the following conditions:

²TEDLAR[®] is a registered trademark of Du Pont.

5.2.2 A water purification system (Millipore Super-Q or equivalent) may also be used to generate reagent water for volatile extractions.

5.2.3 Reagent water for volatile extractions may also be prepared by boiling water for 15 minutes. Subsequently, while maintaining the water temperature at 90 ± 5 degrees C, bubble a contaminant-free inert gas (e.g. nitrogen) through the water for 1 hour. While still hot, transfer the water to a narrow mouth screw-cap bottle under zero-headspace and seal with a Teflon-lined septum and cap.

5.3 Sulfuric acid/nitric acid (60/40 weight percent mixture) H_2SO_4/HNO_3 . Cautiously mix 60 g of concentrated sulfuric acid with 40 g of concentrated nitric acid. If preferred, a more dilute H_2SO_4/HNO_3 acid mixture may be prepared and used in steps 5.4.1 and 5.4.2 making it easier to adjust the pH of the extraction fluids.

5.4 Extraction fluids.

5.4.1 Extraction fluid #1: This fluid is made by adding the 60/40 weight percent mixture of sulfuric and nitric acids (or a suitable dilution) to reagent water (Step 5.2) until the pH is 4.20 ± 0.05 . The fluid is used to determine the leachability of soil from a site that is east of the Mississippi River, and the leachability of wastes and wastewaters.

NOTE: Solutions are unbuffered and exact pH may not be attained.

5.4.2 Extraction fluid #2: This fluid is made by adding the 60/40 weight percent mixture of sulfuric and nitric acids (or a suitable dilution) to reagent water (Step 5.2) until the pH is 5.00 ± 0.05 . The fluid is used to determine the leachability of soil from a site that is west of the Mississippi River.

5.4.3 Extraction fluid #3: This fluid is reagent water (Step 5.2) and is used to determine cyanide and volatiles leachability.

NOTE: These extraction fluids should be monitored frequently for impurities. The pH should be checked prior to use to ensure that these fluids are made up accurately. If impurities are found or the pH is not within the above specifications, the fluid shall be discarded and fresh extraction fluid prepared.

5.5 Analytical standards shall be prepared according to the appropriate analytical method.

6.0 SAMPLE COLLECTION, PRESERVATION, AND HANDLING

6.1 All samples shall be collected using an appropriate sampling plan.

6.2 There may be requirements on the minimal size of the field sample depending upon the physical state or states of the waste and the analytes of concern. An aliquot is needed for the preliminary evaluations of the percent

discussed in Step 4.3.2, and is outlined in Steps 7.1.1.3 through 7.1.1.9.

7.1.1.3 Pre-weigh the filter and the container that will receive the filtrate.

7.1.1.4 Assemble filter holder and filter following the manufacturer's instructions. Place the filter on the support screen and secure.

7.1.1.5 Weigh out a subsample of the waste (100 gram minimum) and record the weight.

7.1.1.6 Allow slurries to stand to permit the solid phase to settle. Samples that settle slowly may be centrifuged prior to filtration. Centrifugation is to be used only as an aid to filtration. If used, the liquid should be decanted and filtered followed by filtration of the solid portion of the waste through the same filtration system.

7.1.1.7 Quantitatively transfer the sample to the filter holder (liquid and solid phases). Spread the sample evenly over the surface of the filter. If filtration of the waste at 4°C reduces the amount of expressed liquid over what would be expressed at room temperature, then allow the sample to warm up to room temperature in the device before filtering.

Gradually apply vacuum or gentle pressure of 1-10 psig, until air or pressurizing gas moves through the filter. If this point is not reached under 10 psig, and if no additional liquid has passed through the filter in any 2-minute interval, slowly increase the pressure in 10 psig increments to a maximum of 50 psig. After each incremental increase of 10 psig, if the pressurizing gas has not moved through the filter, and if no additional liquid has passed through the filter in any 2-minute interval, proceed to the next 10-psig increment. When the pressurizing gas begins to move through the filter, or when liquid flow has ceased at 50 psig (i.e., filtration does not result in any additional filtrate within any 2-minute period), stop the filtration.

NOTE: If sample material (>1 % of original sample weight) has obviously adhered to the container used to transfer the sample to the filtration apparatus, determine the weight of this residue and subtract it from the sample weight determined in Step 7.1.1.5 to determine the weight of the sample that will be filtered.

NOTE: Instantaneous application of high pressure can degrade the glass fiber filter and may cause premature plugging.

7.1.1.8 The material in the filter holder is defined as the solid phase of the sample, and the filtrate is defined as the liquid phase.

7.1.2.4 If the percent dry solids is less than 0.5%, then proceed to Step 7.2.9 if the nonvolatile 1312 analysis is to be performed, and to Step 7.3 if the volatile 1312 analysis is to be performed. If the percent dry solids is greater than or equal to 0.5%, and if the nonvolatile 1312 analysis is to be performed, return to the beginning of this Step (7.1) and, with a fresh portion of sample, determine whether particle size reduction is necessary (Step 7.1.3).

7.1.3 Determination of whether the sample requires particle-size reduction (particle-size is reduced during this step): Using the solid portion of the sample, evaluate the solid for particle size. Particle-size reduction is required, unless the solid has a surface area per gram of material equal to or greater than 3.1 cm^2 , or is smaller than 1 cm in its narrowest dimension (*i.e.*, is capable of passing through a 9.5 mm (0.375 inch) standard sieve). If the surface area is smaller or the particle size larger than described above, prepare the solid portion of the sample for extraction by crushing, cutting, or grinding the waste to a surface area or particle size as described above. If the solids are prepared for organic volatiles extraction, special precautions must be taken (see Step 7.3.6).

NOTE: Surface area criteria are meant for filamentous (*e.g.*, paper, cloth, and similar) waste materials. Actual measurement of surface area is not required, nor is it recommended. For materials that do not obviously meet the criteria, sample-specific methods would need to be developed and employed to measure the surface area. Such methodology is currently not available.

7.1.4 Determination of appropriate extraction fluid:

7.1.4.1 For soils, if the sample is from a site that is east of the Mississippi River, extraction fluid #1 should be used. If the sample is from a site that is west of the Mississippi River, extraction fluid #2 should be used.

7.1.4.2 For wastes and wastewater, extraction fluid #1 should be used.

7.1.4.3 For cyanide-containing wastes and/or soils, extraction fluid #3 (reagent water) must be used because leaching of cyanide-containing samples under acidic conditions may result in the formation of hydrogen cyanide gas.

7.1.5 If the aliquot of the sample used for the preliminary evaluation (Steps 7.1.1 - 7.1.4) was determined to be 100% solid at Step 7.1.1.1, then it can be used for the Step 7.2 extraction (assuming at least 100 grams remain), and the Step 7.3 extraction (assuming at least 25 grams remain). If the aliquot was subjected to the procedure in Step 7.1.1.7, then another aliquot shall be used for the volatile extraction procedure in Step 7.3. The aliquot of the waste subjected to the procedure in Step 7.1.1.7 might be appropriate for use for the Step 7.2 extraction if an adequate amount of solid (as determined by Step 7.1.1.9)

filtration of the solid portion of the waste through the same filtration system.

7.2.7 Quantitatively transfer the sample (liquid and solid phases) to the filter holder (see Step 4.3.2). Spread the waste sample evenly over the surface of the filter. If filtration of the waste at 4°C reduces the amount of expressed liquid over what would be expressed at room temperature, then allow the sample to warm up to room temperature in the device before filtering.

Gradually apply vacuum or gentle pressure of 1-10 psig, until air or pressurizing gas moves through the filter. If this point is not reached under 10 psig, and if no additional liquid has passed through the filter in any 2-minute interval, slowly increase the pressure in 10-psig increments to maximum of 50 psig. After each incremental increase of 10 psig, if the pressurizing gas has not moved through the filter, and if no additional liquid has passed through the filter in any 2-minute interval, proceed to the next 10-psig increment. When the pressurizing gas begins to move through the filter, or when the liquid flow has ceased at 50 psig (i.e., filtration does not result in any additional filtrate within a 2-minute period), stop the filtration.

NOTE: If waste material (>1 % of the original sample weight) has obviously adhered to the container used to transfer the sample to the filtration apparatus, determine the weight of this residue and subtract it from the sample weight determined in Step 7.2.5, to determine the weight of the waste sample that will be filtered.

NOTE: Instantaneous application of high pressure can degrade the glass fiber filter and may cause premature plugging.

7.2.8 The material in the filter holder is defined as the solid phase of the sample, and the filtrate is defined as the liquid phase. Weigh the filtrate. The liquid phase may now be either analyzed (see Step 7.2.12) or stored at 4°C until time of analysis.

NOTE: Some wastes, such as oily wastes and some paint wastes, will obviously contain some material which appears to be a liquid. Even after applying vacuum or pressure filtration, as outlined in Step 7.2.7, this material may not filter. If this is the case, the material within the filtration device is defined as a solid, and is carried through the extraction as a solid. Do not replace the original filter with a fresh filter under any circumstances. Use only one filter.

7.2.9 If the sample contains <0.5% dry solids (see Step 7.1.2), proceed to Step 7.2.13. If the sample contains >0.5 % dry solids (see Step 7.1.1 or 7.1.2), and if particle-size reduction of the solid was needed in Step 7.1.3, proceed to Step 7.2.10. If the sample as received passes a 9.5 mm sieve, quantitatively transfer the solid material into the extractor bottle along with the filter used to separate the initial liquid from the solid phase, and proceed to Step 7.2.11.

in Step 7.2.7. This combined liquid is defined as the 1312 extract. Proceed to Step 7.2.14.

7.2.13.3 If the initial liquid phase of the waste, as obtained from Step 7.2.7, is not or may not be compatible with the filtered liquid resulting from Step 7.2.12, do not combine these liquids. Analyze these liquids, collectively defined as the 1312 extract, and combine the results mathematically, as described in Step 7.2.14.

7.2.14 Following collection of the 1312 extract, the pH of the extract should be recorded. Immediately aliquot and preserve the extract for analysis. Metals aliquots must be acidified with nitric acid to pH < 2. If precipitation is observed upon addition of nitric acid to a small aliquot of the extract, then the remaining portion of the extract for metals analyses shall not be acidified and the extract shall be analyzed as soon as possible. All other aliquots must be stored under refrigeration (4°C) until analyzed. The 1312 extract shall be prepared and analyzed according to appropriate analytical methods. 1312 extracts to be analyzed for metals shall be acid digested except in those instances where digestion causes loss of metallic analytes. If an analysis of the undigested extract shows that the concentration of any regulated metallic analyte exceeds the regulatory level, then the waste is hazardous and digestion of the extract is not necessary. However, data on undigested extracts alone cannot be used to demonstrate that the waste is not hazardous. If the individual phases are to be analyzed separately, determine the volume of the individual phases (to $\pm 0.5\%$), conduct the appropriate analyses, and combine the results mathematically by using a simple volume-weighted average:

$$\text{Final Analyte Concentration} = \frac{(V_1) (C_1) + (V_2) (C_2)}{V_1 + V_2}$$

where:

V_1 = The volume of the first phase (L).

C_1 = The concentration of the analyte of concern in the first phase (mg/L).

V_2 = The volume of the second phase (L).

C_2 = The concentration of the analyte of concern in the second phase (mg/L).

7.2.15 Compare the analyte concentrations in the 1312 extract with the levels identified in the appropriate regulations. Refer to Section 8.0 for quality assurance requirements.

7.3 Procedure When Volatiles Are Involved

Use the ZHE device to obtain 1312 extract for analysis of volatile compounds only. Extract resulting from the use of the ZHE shall not be used to evaluate the mobility of non-volatile analytes (e.g., metals, pesticides, etc.).

$$\text{Weight of waste to charge ZHE} = \frac{25}{\text{percent solids (Step 7.1.1)}} \times 100$$

Weigh out a subsample of the waste of the appropriate size and record the weight.

7.3.5 If particle-size reduction of the solid portion of the sample was required in Step 7.1.3, proceed to Step 7.3.6. If particle-size reduction was not required in Step 7.1.3, proceed to Step 7.3.7.

7.3.6 Prepare the sample for extraction by crushing, cutting, or grinding the solid portion of the waste to a surface area or particle size as described in Step 7.1.3.1. Wastes and appropriate reduction equipment should be refrigerated, if possible, to 4°C prior to particle-size reduction. The means used to effect particle-size reduction must not generate heat in and of itself. If reduction of the solid phase of the waste is necessary, exposure of the waste to the atmosphere should be avoided to the extent possible.

NOTE: Sieving of the waste is not recommended due to the possibility that volatiles may be lost. The use of an appropriately graduated ruler is recommended as an acceptable alternative. Surface area requirements are meant for filamentous (e.g., paper, cloth) and similar waste materials. Actual measurement of surface area is not recommended.

When the surface area or particle-size has been appropriately altered, proceed to Step 7.3.7.

7.3.7 Waste slurries need not be allowed to stand to permit the solid phase to settle. Do not centrifuge samples prior to filtration.

7.3.8 Quantitatively transfer the entire sample (liquid and solid phases) quickly to the ZHE. Secure the filter and support screens into the top flange of the device and secure the top flange to the ZHE body in accordance with the manufacturer's instructions. Tighten all ZHE fittings and place the device in the vertical position (gas inlet/outlet flange on the bottom). Do not attach the extraction collection device to the top plate.

Note: If sample material (>1% of original sample weight) has obviously adhered to the container used to transfer the sample to the ZHE, determine the weight of this residue and subtract it from the sample weight determined in Step 7.3.4 to determine the weight of the waste sample that will be filtered.

Attach a gas line to the gas inlet/outlet valve (bottom flange) and, with the liquid inlet/outlet valve (top flange) open, begin applying gentle pressure of 1-10 psig (or more if necessary) to force all headspace slowly out of the ZHE device into a hood. At the first appearance of liquid from the liquid inlet/outlet valve, quickly close the valve and discontinue pressure. If filtration of the waste at 4°C reduces the

7.3.12.1 With the ZHE in the vertical position, attach a line from the extraction fluid reservoir to the liquid inlet/outlet valve. The line used shall contain fresh extraction fluid and should be preflushed with fluid to eliminate any air pockets in the line. Release gas pressure on the ZHE piston (from the gas inlet/outlet valve), open the liquid inlet/outlet valve, and begin transferring extraction fluid (by pumping or similar means) into the ZHE. Continue pumping extraction fluid into the ZHE until the appropriate amount of fluid has been introduced into the device.

7.3.12.2 After the extraction fluid has been added, immediately close the liquid inlet/outlet valve and disconnect the extraction fluid line. Check the ZHE to ensure that all valves are in their closed positions. Manually rotate the device in an end-over-end fashion 2 or 3 times. Reposition the ZHE in the vertical position with the liquid inlet/outlet valve on top. Pressurize the ZHE to 5-10 psig (if necessary) and slowly open the liquid inlet/outlet valve to bleed out any headspace (into a hood) that may have been introduced due to the addition of extraction fluid. This bleeding shall be done quickly and shall be stopped at the first appearance of liquid from the valve. Re-pressurize the ZHE with 5-10 psig and check all ZHE fittings to ensure that they are closed.

7.3.12.3 Place the ZHE in the rotary extractor apparatus (if it is not already there) and rotate at 30 ± 2 rpm for 18 ± 2 hours. Ambient temperature (i.e., temperature of room in which extraction occurs) shall be maintained at $23 \pm 2^{\circ}\text{C}$ during agitation.

7.3.13 Following the 18 ± 2 hour agitation period, check the pressure behind the ZHE piston by quickly opening and closing the gas inlet/outlet valve and noting the escape of gas. If the pressure has not been maintained (i.e., no gas release observed), the ZHE is leaking. Check the ZHE for leaking as specified in Step 4.2.1, and perform the extraction again with a new sample of waste. If the pressure within the device has been maintained, the material in the extractor vessel is once again separated into its component liquid and solid phases. If the waste contained an initial liquid phase, the liquid may be filtered directly into the same filtrate collection container (i.e., TEDLAR® bag) holding the initial liquid phase of the waste. A separate filtrate collection container must be used if combining would create multiple phases, or there is not enough volume left within the filtrate collection container. Filter through the glass fiber filter, using the ZHE device as discussed in Step 7.3.9. All extracts shall be filtered and collected if the TEDLAR® bag is used, if the extract is multiphasic, or if the waste contained an initial liquid phase (see Steps 4.6 and 7.3.1).

NOTE: An in-line glass fiber filter may be used to filter the material within the ZHE if it is suspected that the glass fiber filter has been ruptured

spike concentration may be as low as one half of the analyte concentration, but may not be less than five times the method detection limit. In order to avoid differences in matrix effects, the matrix spikes must be added to the same nominal volume of 1312 extract as that which was analyzed for the unspiked sample.

8.2.3 The purpose of the matrix spike is to monitor the performance of the analytical methods used, and to determine whether matrix interferences exist. Use of other internal calibration methods, modification of the analytical methods, or use of alternate analytical methods may be needed to accurately measure the analyte concentration in the 1312 extract when the recovery of the matrix spike is below the expected analytical method performance.

8.2.4 Matrix spike recoveries are calculated by the following formula:

$$\%R (\% \text{ Recovery}) = 100 (X_s - X_u) / K$$

where:

X_s = measured value for the spiked sample

X_u = measured value for the unspiked sample, and

K = known value of the spike in the sample.

8.3 All quality control measures described in the appropriate analytical methods shall be followed.

8.4 The use of internal calibration quantitation methods shall be employed for a metallic contaminant if: (1) Recovery of the contaminant from the 1312 extract is not at least 50% and the concentration does not exceed the appropriate regulatory level, and (2) The concentration of the contaminant measured in the extract is within 20% of the appropriate regulatory level.

8.4.1. The method of standard additions shall be employed as the internal calibration quantitation method for each metallic contaminant.

8.4.2 The method of standard additions requires preparing calibration standards in the sample matrix rather than reagent water or blank solution. It requires taking four identical aliquots of the solution and adding known amounts of standard to three of these aliquots. The fourth aliquot is the unknown. Preferably, the first addition should be prepared so that the resulting concentration is approximately 50% of the expected concentration of the sample. The second and third additions should be prepared so that the concentrations are approximately 100% and 150% of the expected concentration of the sample. All four aliquots are maintained at the same final volume by adding reagent water or a blank solution, and may need dilution adjustment to maintain the signals in the linear range of the instrument technique. All four aliquots are analyzed.

8.4.3 Prepare a plot, or subject data to linear regression, of instrument signals or external-calibration-derived concentrations as the dependant variable (y-axis) versus concentrations of the additions of standards as the independent variable (x-axis). Solve for the intercept

by the moderate relative standard deviations (RSDs) of the recoveries (averaging 29% for the compounds and elements analyzed).

9.2 Precision results for volatiles: Four different soils were spiked and tested for the extraction of volatiles. Soils One and Two were from western and eastern Superfund sites. Soils Three and Four were mixtures of a western soil with low organic content and two different municipal sludges. The results are shown in Table 7. Extract concentrations of volatile organics from the eastern soil were lower than from the western soil. Replicate leachings of Soils Three and Four showed lower precision than the leachates from the Superfund soils.

10.0 REFERENCES

1. Environmental Monitoring Systems Laboratory, "Performance Testing of Method 1312: QA Support for RCRA Testing: Project Report". EPA/600/4-89/022. EPA Contract 68-03-3249 to Lockheed Engineering and Sciences Company, June 1989.
2. Research Triangle Institute, "Interlaboratory Comparison of Methods 1310, 1311, and 1312 for Lead in Soil". U.S. EPA Contract 68-01-7075, November 1988.

Table 2. Suitable Rotary Agitation Apparatus¹

Company	Location	Model No.
Analytical Testing and Consulting Services, Inc.	Warrington, PA (215) 343-4490	4-vessel extractor (DC20S); 8-vessel extractor (DC20); 12-vessel extractor (DC20B)
Associated Design and Manufacturing Company	Alexandria, VA (703) 549-5999	2-vessel (3740-2); 4-vessel (3740-4); 6-vessel (3740-6); 8-vessel (3740-8); 12-vessel (3740-12); 24-vessel (3740-24)
Environmental Machine and Design, Inc.	Lynchburg, VA (804) 845-6424	8-vessel (08-00-00) 4-vessel (04-00-00)
IRA Machine Shop and Laboratory	Santurce, PR (809) 752-4004	8-vessel (011001)
Lars Lande Manufacturing	Whitmore Lake, MI (313) 449-4116	10-vessel (10VRE) 5-vessel (5VRE)
Millipore Corp.	Bedford, MA (800) 225-3384	4-ZHE or 4 1-liter bottle extractor (YT300RAHW)

¹ Any device that rotates the extraction vessel in an end-over-end fashion at 30 $\pm$ 2 rpm is acceptable.

Table 4. Suitable Filter Holders¹

Company	Location	Model/ Catalogue #	Size
Nucleopore Corporation	Pleasanton, CA (800) 882-7711	425910 410400	142 mm 47 mm
Micro Filtration Systems	Dublin, CA (800) 334-7132 (415) 828-6010	302400 311400	142 mm 47 mm
Millipore Corporation	Bedford, MA (800) 225-3384	YT30142HW XX1004700	142 mm 47 mm

¹ Any device capable of separating the liquid from the solid phase of the waste is suitable, providing that it is chemically compatible with the waste and the constituents to be analyzed. Plastic devices (not listed above) may be used when only inorganic analytes are of concern. The 142 mm size filter holder is recommended.

Table 5. Suitable Filter Media¹

Company	Location	Model	Pore Size (μ m)
Millipore Corporation	Bedford, MA (800) 225-3384	AP40	0.7
Nucleopore Corporation	Pleasanton, CA (415) 463-2530	211625	0.7
Whatman Laboratory Products, Inc.	Clifton, NJ (201) 773-5800	GFF	0.7
Micro Filtration Systems	Dublin, CA (800) 334-7132 (415) 828-6010	GF75	0.7

¹ Any filter that meets the specifications in Step 4.4 of the Method is suitable.

TABLE 7 - METHOD 1312 PRECISION RESULTS FOR VOLATILES

Compound Name	Soil No. 1		Soil No. 2		Soil No. 3		Soil No. 4	
	(Western)		(Eastern)		(Western and Sludge)		(Western and Sludge)	
	Avg. %Rec.*	%RSD	Avg. %Rec.*	%RSD	Avg. %Rec.**	%RSD	Avg. %Rec.***	%RSD
Acetone	44.0	12.4	43.8	2.25	116.0	11.5	21.3	71.4
Acrylonitrile	52.5	68.4	50.5	70.0	49.3	44.9	51.8	4.6
Benzene	47.8	8.29	34.8	16.3	49.8	36.7	33.4	41.1
n-Butyl Alcohol (1-Butanol)	55.5	2.91	49.2	14.6	65.5	37.2	73.0	13.9
Carbon disulfide	21.4	16.4	12.9	49.5	36.5	51.5	21.3	31.5
Carbon tetrachloride	40.6	18.6	22.3	29.1	36.2	41.4	24.0	34.0
Chlorobenzene	64.4	6.76	41.5	13.1	44.2	32.0	33.0	24.9
Chloroform	61.3	8.04	54.8	16.4	61.8	29.1	45.8	38.6
1,2-Dichloroethane	73.4	4.59	68.7	11.3	58.3	33.3	41.2	37.8
1,1-Dichloroethane	31.4	14.5	22.9	39.3	32.0	54.4	16.8	26.4
Ethyl acetate	76.4	9.65	75.4	4.02	23.0	119.8	11.0	115.5
Ethylbenzene	56.2	9.22	23.2	11.5	37.5	36.1	27.2	28.6
Ethyl ether	48.0	16.4	55.1	9.72	37.3	31.2	42.0	17.6
Isobutanol (4-Methyl -1-propanol)	0.0	ND	0.0	ND	61.8	37.7	76.0	12.2
Methylene chloride	47.5	30.3	42.2	42.9	52.0	37.4	37.3	16.6
Methyl ethyl ketone (2-Butanone)	56.7	5.94	61.9	3.94	73.7	31.3	40.6	39.0
Methyl isobutyl ketone	81.1	10.3	88.9	2.99	58.3	32.6	39.8	40.3
1,1,1,2-Tetrachloro- ethane	69.0	6.73	41.1	11.3	50.8	31.5	36.8	23.8
1,1,2,2-Tetrachloro- ethane	85.3	7.04	58.9	4.15	64.0	25.7	53.6	15.8
Tetrachloroethene	45.1	12.7	15.2	17.4	26.2	44.0	18.6	24.2
Toluene	59.2	8.06	49.3	10.5	45.7	35.2	31.4	37.2
1,1,1-Trichloro- ethane	47.2	16.0	33.8	22.8	40.7	40.6	26.2	38.8
1,1,2-Trichloro- ethane	76.2	5.72	67.3	8.43	61.7	28.0	46.4	25.4
Trichloroethene	54.5	11.1	39.4	19.5	38.8	40.9	25.6	34.1
Trichloro- fluoromethane	20.7	24.5	12.6	60.1	28.5	34.0	19.8	33.9
1,1,2-Trichloro- trifluoroethane	18.1	26.7	6.95	58.0	21.5	67.8	15.3	24.8
Vinyl chloride	10.2	20.3	7.17	72.8	25.0	61.0	11.8	25.4

* Triplicate analyses

** Six replicate analyses

*** Five replicate analyses

SYNTHETIC PRECIPITATION LEACHING PROCEDURE

